
DATA SHEET

Liquid Level Switches

Optomax Basic Series



- Liquid level switches that can detect almost any liquid type; oil or water based
- Choice of material; Polysulfone (standard) or Trogamid®
- Choice of threads and terminal connections



Housing/ Mounting M10x1 M12x1 NPT

Output Type / Logic





Supply Voltage





Output Current





Temp



BENEFITS

- OEM optics only solution1
- Low cost
- Compact design

OUTPUT VALUES

Refer to Circuit Diagram section on page 3 for details.

TECHNICAL SPECIFICATIONS

Supply voltage (Vs)

LED forward current (If) Output signal

Any with suitable LED current limiting resistor

10mA recommended Phototransistor open collector.

Refer to Circuit Diagram section on page 3

Operating temperatures Storage temperatures Housing material² Sensor termination

Standard: -25°C to +80°C Standard: -30°C to +85°C Polysulfone or Trogamid® 24AWG, 250mm PTFE wires, 8mm tinned



- Minimum order quantity of 500 applies.
- Before use check that the fluid in which you wish to use these devices is compatible either with Polysulfone or Trogamid®.

Apollosense Ltd

Adress: Room 712, Huaneng Building, Shennan Zhong Road, Shenzhen 518031,

Tel: (86-755) 83680810 83680820 83680830 83680860 Fax: (86-755) 83680866

Adress: Unit 1502, Hollywood Plaza, 610 Nathan Road, Mong Kok, Kln., H.K.


Tel: (852) 2737 0903 Fax: (852) 2737 0938 Email: sales@apollounion.com



OUTLINE DRAWING


All dimensions shown in mm. Tolerances = ± 1 mm.

LLx500 Series





LLx200 Series






LLx600 Series





LLx700 Series





	Housing Series				
	500	200	600	700	
Thread	M10x1	M12x1x8g with hex nut ¹	1/2" SAE with O-ring ¹	1/4" NPT ²	
Pressure	20 bar / 209 psi max.	7 bar / 101 psi maximum			
Tightening Torque	1.5 Nm / 13.26 in-lbs maximum				

ELECTRICAL INTERFACE

Flying Leads—3-wire option

Wire	Designation	
Red	LED _{ANODE}	
Green	Output	
Blue	0V	

Flying Leads—4-wire option

Wire	Designation		
Red	LED _{ANODE}		
Green	Output		
Blue	0V LED		
Black	0V Phototransistor		

Apollosense Ltd

Tel: (86-755) 83680810 83680820 83680830 83680860 Fax: (86-755) 83680866

Tel: (852) 2737 0903

Fax: (852) 2737 0938 Email: sales@apollounion.com






Flying Leads—3-wire option

R_{LED} R_{PULL-UP} OUTPUT

Flying Leads—4-wire option



Note: The 4-wire version provides galvanic isolation between input (IR-LED) and output (Phototransistor).

Pre-selected R _{LED} and R _{PULL-UP} Value for Different Supply Voltages						
Vs	R _{LED}	R _{PULL-UP}	V _{OUTPUT} in Air	V _{OUTPUT} in Water		
3.3V	200R	2K	< 0.75V	> 2.5V		
5V	360R	2K	< 1V	> 4.25V		
8V	680R	2.5K	< 1.5V	> 7.25V		
12V	1K	3K	< 3V	> 11.25V		
15V	1.3K	3.5K	< 3.25V	> 14.25V		
24V	2.2K	4K	< 10.5V	> 22.5V		

Typical installation: You must select suitable resistors for your chosen supply voltage. Forward voltage of LED is 1.3V and LED current should be 10mA (depending on application liquid). Therefore, for a supply of Vs = 5V for example:

$$R_{LED} = \frac{(V_s - 1.3)V}{10mA} = \frac{5 - 1.3}{0.01} = 370\Omega \approx 360\Omega$$
 (standard value)

CAUTION: Failure to select the correct resistor values may result in damage to the sensor.

The minimum value of $R_{\text{PULL-UP}}$ should not exceed Vs/max output current.

Note: Shorting the output to Vs will result in irreparable damage to the sensor.

Apollosense Ltd

Tel: (86-755) 83680810 83680820 83680830 83680860 Fax: (86-755) 83680866 Hong Kong:

Adress: Unit 1502, Hollywood Plaza, 610 Nathan Road, Mong Kok, Kln., H.K.


Tel: (852) 2737 0903 Fax: (852) 2737 0938 Email: sales@apollounion.com






Generate your specific part number using the convention shown opposite. Use only those letters and numbers that correspond to the sensor and output options you require — omit those you do not.

Sensor mounted from inside vessel



Sensor mounted from outside vessel



Notes:

- 500 series sensors are mounted internally
- 200, 600 & 700 series sensors are mounted externally
- SH suffix applicable to 200, 600 & 700 series sensors only; omit from 500 series sensor part number



Do not exceed maximum ratings and ensure sensor(s) are operated in accordance with their requirements.

Carefully follow all wiring instructions. Incorrect wiring can cause permanent damage to the device.

Apollosense Ltd recommend using alcohol based cleaning agents. Do NOT use chlorinated solvents such as trichloroethane as these are likely to attack the sensor material.

Failure to comply with these instructions may result in product damage.

1 INFORMATION

As customer applications are outside of Apollosense Ltd.'s control, the information provided is given without legal responsibility. Customers should test under their own conditions to ensure that the equipment is suitable for their intended application. Before use, check that the fluid in which you wish to use these devices is compatible with Polysulfone or Trogamid®.

General Note: Apollosense Ltd. reserves the right to make changes to product specifications without notice or liability. All information is subject to Apollosense Ltd.'s own data and considered accurate at time of going to print.

Apollosense Ltd

Shenzhen:

Adress: Room 712, Huaneng Building, Shennan Zhong Road, Shenzhen 518031,

China

Tel: (86-755) 83680810 83680820 83680830 83680860 Fax: (86-755) 83680866

Adress: Unit 1502, Hollywood Plaza, 610 Nathan Road, Mong Kok, Kln., H.K. Tel: (852) 2737 0903

Tel:(852) 2737 0903

Fax:(852) 2737 0938

Email:sales@apollounion.com

Hong Kong: